Attention

During the assembly of the Tape Backup unit in the Altos R710 or Altos R720, by using the Tape conversion Kit (P/N: S0.R0703.010 , S0.R0703.009), please use only the screw holes #2 and #3. Please don't use the first screw hole #1 as it could possibly damage the Tape Backup Unit.